



Cleaning & Decontamination

Tough-PAC® is a hard shell anti-microbial case for mobile computers. A silver biocide 'Biomaster' is permanently built in to the casing during manufacture. An antibacterial screen protector is also used.

Day-to-day cleaning should still be carried out as part of any infection or decontamination control policy. These recommendations apply to all Tough-PAC® products.

In all cases consult your local infection control team, policies and procedures.

General day-to day cleaning

- Wear appropriate PPE.
- Turn off iPad using the sleep button in the handle aperture.
- Clean all external surfaces of Tough-PAC using a moist general cleaning wipe*.
- Dry the surfaces and screen using a clean microfibre cloth.

**Follow the user instructions for the cleaning product used.*



Suggested general cleaning products

- ✓ Clinell® Detergent wipes
- ✓ Clinell® Universal wipes
- ✓ Clinell® Alcohol wipes
- ✓ Synergy Health AzoActive wipes
- ✓ Synergy Health AzoMax wipes

Tough-PAC® Designed in Hampshire, Made in Britain

European Registered Designs 1962978, 20154070 Copy & Design Rights Reserved





Cleaning for outbreaks or Isolation

- ✓ Wear appropriate PPE.
- ✓ Turn off iPad using the sleep button in the handle aperture.
- ✓ Clean all external surfaces of Tough-PAC using a moist decontamination wipe, air dry*.
- ✓ Clean again using a detergent wipe particularly the front screen and case contacts (to remove residues)
- ✓ Dry the surfaces and screen with a clean microfibre cloth.

**0.1-0.5% bleach or a peracetic acid wipe. Follow the user instructions for the cleaning product.*

Suggested products

- ✓ Clinell® 'Clorox' wipes
- ✓ Clinell® Sporocidal wipes
- ✓ Clinell® Detergent wipes
- ✓ Guest Medical Chlor-Clean wipes



Cleaning for body fluid contamination

- Wear appropriate PPE.
- Turn off iPad using the sleep button in the handle aperture.
- Remove all gross contamination*.
- Clean all external surfaces of Tough-PAC using a moist chlorinated** cleaning wipe, air dry.
- Clean again using a detergent wipe particularly the front screen and case contacts (to remove residues)
- Dry the surfaces and screen with a clean micro-fibre cloth.

**If contamination has been rinsed/washed off with a cleaning solution we advise opening the case after cleaning, when completely dry externally to check for any fluid ingress; if present it must be removed. Replace the screen and port plugs on reassembly. Tough-PAC is not 100% waterproof – do not immerse in fluid.*

***0.5% bleach (5200ppm available chlorine) Follow the user instructions for the cleaning product.*

Suggested products

- ✓ Clinell® 'Clorox' wipes
- ✓ Clinell® Detergent wipes
- ✓ Guest Medical Chlor-Clean wipes

The Clinell® range of products have been tested on Tough-PAC and not found to cause any significant harm to the product. Others include 100% isopropyl alcohol, household Dettol multi-action and Power & Pure antibacterial sprays, Flash with bleach, Flash cleaning wipes. Synergy Health AzoActive, AzoMax, AzoWipette. Guest Medical Chlor-clean wipes

